

WAGNERS

COMPOSITE FIBRE TECHNOLOGIES (CFT)

CRICKET PITCHES



Wagners cricket pitches are lightweight and effortless to install. Depending on the field capacity, each section of the pitch can be placed using a truck-mounted crane or a small excavator.

Measuring up to 8.8 metres, each panel is compact and fitted with concealed lifting lugs that fit on most flat-bed long trailers. The panels can be stacked for easy transportation and storage.

A CONSTANT AND TRUE BOUNCE.

Wagners cricket pitches are uniquely suited to withstand Australia's harshest weather while providing minimal maintenance.

PITCH FEATURES

- » Glass fibre reinforced sub-structure
- » 25 years design life
- » Fibre cement deck
- » Synthetic grass cover options:
 - » *Synthetic grass polypropylene*
 - » *Synthetic grass nylon super turf*

**PLAY ON YOUR
CENTRE OVAL
ALL YEAR
ROUND WITH
WAGNERS
CRICKET
PITCHES.**

WAGNERS

COMPOSITE FIBRE TECHNOLOGIES (CFT)

CRICKET PITCHES

PITCH SIZES

Available in two standard lengths, both lengths feature 22 yards of wicket to wicket spacing.

- » The "Spinner": 25.9 m high x 2.4 m wide (short run up)
- » The "Paceman": 37.7 m high x 2.4 m wide (long run up)



Assembled in a controlled environment with precise consistencies and attention to detail, a Wagners cricket pitch assures the pitch is fit for purpose. Possessing a full in-house design team, Wagners work closely with the client to ensure a dependable, high quality cricket pitch that provides an optimum and safe playing surface.

INJURY PREVENTION

Australia's love of sport means the same ovals are used for multiple codes throughout the year.

Falling on a concrete cricket pitch while playing football can lead to serious injury to children and professional athletes alike. While pitches should be covered with a soft surface, these surfaces can be disturbed once a football match has begun. Wagners composite cricket pitches provide a safe surface for all players all year round with the added bonus of reduced injuries commonly experienced on shared grounds.

EASY INSTALLATION

- 1 Prepare shallow trench (the area where your pitch is to be prepared).
- 2 Screed a stable base in the trench.
- 3 Place the Wagners cricket pitch onto the pad.
- 4 Turf off the edges. Add a top dress and compact to suit.



CONTACT US



+61 (0) 7 4637 7777



CFTSALES@WAGNER.COM.AU